

Sungrow Inverter Integration Guide

V2.2 - June 2025


Read this first	2
How are Sungrow Inverters integrated with the CET system?	2
When is a data connection to an Inverter required?	2
Is a Sungrow meter also required?	3
Data connection	3
Enable Modbus TCP and Check Forwarding Modbus ID	4
Battery Configuration	5
The CET device should be powered from the backup circuit	5
Contact CET Support to test the data connection	5
Steps to Connect to Inverter	6
SH-K Series	6
SG-K Series	7
SG-RS Series	7
SG-RT Series	8
SH-RS Series	9
SH-RT Series	10
WiNet-S/S2 Ethernet Connection	11
Steps to Connect to CET Device	13
Power Meter (EMU system)	13
Gateway One	14

Read this first


How are Sungrow Inverters integrated with the CET system?

Sungrow Inverters are integrated with the CET system by adding an Ethernet connection between the CET device (Power Meter / Gateway One / etc) and the Inverter. For some inverter models a **WiNet-S** or **WiNet-S2 Communication Module** is required to add Ethernet to the inverter.

Example of new system (EMU + Power Meter)



Example of old system (Gateway One)




When is a data connection to an Inverter required?

1. When the CET system is responsible for **export limiting** or **CSIP-AUS** compliance
2. When there is a **battery** connected to the Inverter

Is a Sungrow meter also required?

Yes. Unlike other inverter brands, Sungrow inverters require a Sungrow power meter to function even when under full HEMS control.

For sites requiring battery control, please clip the Sungrow meter CT onto the inverter supply line as shown in the image below.



Data connection

The Ethernet connection provides a Modbus data connection for the CET system and also provides the inverter with a connection to the Internet.


Some Sungrow inverters models have built-in Ethernet and can be connected without an adapter. Most Sungrow inverter models however require a **WiNet-S or WiNet-S2 Communication Module** to add Ethernet.



Please Note: For the Sungrow Monitoring System, when Sungrow inverters are registered in their portal, this is done using the serial number of both the inverter and the Communications Module. If a new module is installed (for e.g. when swapping a Wi-Fi only dongle with the WiNet Module), ensure the serial number of the new module is entered in their portal as well, to successfully connect to the Sungrow Monitoring.

Enable Modbus TCP and Check Forwarding Modbus ID


For the CET HEMS to be able to communicate with the Sungrow inverter, Modbus TCP must be enabled on port 502 via the WiNet-S2 web interface (System->Forwarding Configuration):



The screenshot shows the WiNet-S2 web interface. On the left is a sidebar menu with 'System' expanded and 'Forwarding Configuration' selected. The main content area shows the 'MODBUS' tab. A table lists local ports and their corresponding switches and SSL encryption settings. A red arrow points to the 'Switch' column for port 502, which is currently turned on.

Local Port	Switch	SSL Encryption
502	<input checked="" type="checkbox"/>	<input type="checkbox"/>
516	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Please confirm the Forwarding Modbus ID for the inverter in the Device List page (Device -> Device List). In this example the SH10RS inverter has been allocated Forwarding Modbus ID 3 by the WiNet-S2:



The screenshot shows the WiNet-S2 web interface with the 'Device List' page selected. A table lists devices with their details. The 'SH10RS' device model and its 'Forwarding Modbus ID' of 3 are highlighted with red boxes.

No.	S/N	Device Name	Device Model	Port	Device Address	Forwarding Modbus ID	Com Status	Action
1	A2511511015	SH10RS(COM1-002)	SH10RS	COM1	2	3		
2	S2404227515	SBH200-V11(COM1-200)	SBH200-V11	COM1	200	4		

Please provide this ID to CET when commissioning and testing the system.

Battery Configuration

Please refer to the Sungrow documentation for the latest instructions on configuring a battery. Once the battery has been properly configured, the CET system will be able to use the data connection to control the battery.

The CET device should be powered from the backup circuit

If a hybrid inverter with battery is being installed, the CET device (Gateway / Power Meter / etc) should be powered from the backup circuit so that it will continue to operate during blackouts.

If a single-phase backup is being provided at a two-phase or three-phase site, the backed up circuit should be connected to the **Phase A** terminal of the CET device.

Contact CET Support to test the data connection

When the data connection to the inverter is ready to test, contact CET by logging in to the *onSite* web app at <http://onsite.combined.energy/> and using the **Request Support** button in the menu.

Steps to Connect to Inverter

Sungrow inverters over Ethernet use Modbus TCP on port 502. A **double-insulated Ethernet cable** with a standard T568A or T568B pinout at both ends will be required.


The images shown here are for reference only. The actual product received may differ if modified by Sungrow.

SH-K Series

E.g. SH5K

The Ethernet connector on the SH-K is located under the cover.

1. Prepare a **double-insulated Ethernet cable** with a standard T568A or T568B pinout at both ends.
2. Connect the Ethernet cable to the SH-K inverter as shown below:




3. Connect the Ethernet cable to the CET device in accordance with the specific steps for the device in the [Steps to Connect to CET Device](#) section of this document.

SG-K Series

Not supported - this inverter series does not have a supported Ethernet adapter from Sungrow and is therefore not supported by CET HEMS.

SG-RS Series


1. Prepare a **double-insulated Ethernet cable** with a standard T568A or T568B pinout at both ends.
2. Connect the WiNet-S or WiNet-S2 Communication Module to the **COM1** port of the inverter (labelled "2" below). This will enable Ethernet communications. Instructions on how to connect the Ethernet cable to the module can be found in the [WiNet-S/S2 Ethernet Connection](#) section of this document.



3. Connect the Ethernet cable to the CET device in accordance with the specific steps for the device in the [Steps to Connect to CET Device](#) section of this document.

SG-RT Series


1. Prepare a **double-insulated Ethernet cable** with a standard T568A or T568B pinout at both ends.
2. Connect the WiNet-S or WiNet-S2 Communication Module to the **COM1** port of the inverter (labelled “2” below). This will enable Ethernet communications. Instructions on how to connect the Ethernet cable to the module can be found in the [WiNet-S/S2 Ethernet Connection](#) section of this document.



3. Connect the Ethernet cable to the CET device in accordance with the specific steps for the device in the [Steps to Connect to CET Device](#) section of this document.

SH-RS Series

1. Prepare a double-insulated Ethernet cable with a standard T568A or T568B pinout at both ends.
2. Connect the WiNet-S or WiNet-S2 Communication Module to the **COM1** port of the inverter (labelled “4” below). Instructions on how to connect the Ethernet cable to the module can be found in the [WiNet-S/S2 Ethernet Connection](#) section of this document.




3. Connect the Ethernet cable to the CET device in accordance with the specific steps for the device in the [Steps to Connect to CET Device](#) section of this document.

SH-RT Series

Use the **LAN Terminal** in the inverter (labelled “4” below) to connect the Ethernet cable.

1. Prepare a double-insulated Ethernet cable with a standard T568A or T568B pinout at both ends.
2. Unscrew the waterproof lid from the LAN terminal and insert the Ethernet connector.
3. Ensure cables are fastened firmly and tighten the swivel nut.




4. Connect the Ethernet cable to the CET device in accordance with the specific steps for the device in the [Steps to Connect to CET Device](#) section of this document.

WiNet-S/S2 Ethernet Connection


The WiNet-S module supports Ethernet communication and WLAN communication. It is not recommended to use both communication methods at the same time. The EMU will provide an Internet connection to the inverter if the inverter is connected via Ethernet, so a Wi-Fi connection is not required.

Further information can be found in the User Manual for the respective inverter.


1. Prepare the double-insulated Ethernet cable with a standard T568A or T568B pinout.
2. Unscrew the swivel nut, take out the inner sealing ring and unscrew the housing from the communication module.




3. Thread the network cable through the swivel nut and gasket, route the cable into the opening of the sealing and insert the cable through the housing.



4. Insert the RJ45 plug into the front plug connector until there is an audible click and attach the housing, gasket and swivel nut.




5. Remove the waterproof lid from the COM1 terminal and install WiNet-S/S2.




Steps to Connect to CET Device

Power Meter (EMU system)

1. Using a flat blade screwdriver, carefully remove the breakout tab covering the RJ45 "Ethernet" port:



2. Connect the inverter to the RJ45 port using a **double insulated** Ethernet cable (e.g. Clipsal 5005C305B).



Gateway One

Terminate the **double-insulated** Ethernet cable and plug the cable into the Ethernet port on the **far right-hand side** of the Gateway:

